HOW TO OPERATE

Power Toggle Control
Step to the next color or brightness level.

Push Button Control
Press button to access light 'Modes' such as fade and strobe.

RECOMMENDED WIRE GAUGES

Scan the QR Code or click **here** to view our recommended wire gauge chart.

SCM-PD-RELAY-4
(Includes 4 X 10A Fuses)

10   10   10   10

LIGHT 1   LIGHT 2   LIGHT 3   LIGHT 4

Breaker

BUSS
MRCB
50A

Battery
24V or 12V DC

To
SCM-PD-RELAY4

+12V for
Turn On

8 ⬆   ⬆ 7
2   4
  5
3   6

(Back side of switch)

To Power
Source

Ground
In

SCM-SWITCH-O/O/
MOMENTARY

SCR-24 Underwater Lights