
SCM-PWR6 with SCM-LC-N2K-PLUS & 6 Single Color Lights



Standard Layout



Multi-Function Display

ies ia	(4				=	
BLUE	WHITE	RED	GREEN			
ROTATE ALL	DIMMED	нусам	BLUE WHITE	MUSIC		
Ughting Controller	2 2 Zone 3	Zone 4	Zone 5	Prisas and light to still a	5	
				Low		
	_					
Setter:	Sendal Sen	aha Samad-f	Sweens	Switchen	-	
					*	
				0	\sim	
er (99)						
ch-2	Switch-3	Sv	vitch-4	Switch-5		Switch-6
01172						

Shadow-Caster User Interface Switch Controls

ch State	Action
ON	First click on switch
ON/OFF	Press and hold 2nd click on switch. All switches will flip their state.
EXT SWITCH	Quickly power off switch then power back on. Then give a 2nd click to identify the currently selected switch.
TATE ON/OFF	Quickly 2nd click the switch. The state will be represented in GREEN/ON or RED/OFF.
OFF DEVICE	Flip the physical switch into the off state. All digital switches and the PW6 will go to OFF state.