# **SCM Switch with SCR Series Underwater Lights**



## **HOW TO OPERATE**

#### Power Toggle Control

Step to the next color or brightness level.

#### **Push Button Control**

Press button to access light 'Modes' such as fade and strobe.

### **RECOMMENDED WIRE GAUGES**

Scan the QR Code or click here to view our recommended wire gauge chart.








(SC

SCM-SWITCH-0/0/ **MOMENTARY** 

**SCR Series Underwater Light** SCM-Switch-O/O/MOMENTARY (20A Max)

2x SCR 24s at 10A each or 3x SCR-16s at 6.4A each

Shadow-NET wires are not connected when using a switch.



PIN	NAME
2	Power Switched
3	Switch LED
5	Momentary Out
6	Momentary In
7	GND
8	Power Switched